



TransLogic® Nexus Panel Cleaning Guideline

Cleaning Your Touchscreen

- Never use organic solvents on the touchscreen
- Do not spray any liquid directly onto the screen
- Clean the screen with soft cloth or paper towel dampened with cleaning solution
- Do not clean the touch screen with strong chemicals
- Do not apply any liquid on the edges of the touchscreen

Several of our customers have been using the following cleaning product (Sani-Cloth AF3) with great results. Swisslog Healthcare does not make or sell this product. This product and other products alike are available in specialties stores where cleaning supplies are sold.



More about this product:

- Alcohol free. Fragrance free. Worry free
- Quat based surface disinfection that is effective against 44 microorganisms in 3 minutes
- Fragrance free formulation; no harsh odors
- Perfect for equipment and other hard surfaces sensitive to alcohol
- Alcohol, fragrance, bleach, acid, phenol, acetone, and ammonia free

CONTACT

Swisslog Healthcare
healthcare.us@swisslog.com
 800.764.0300
swisslog-healthcare.com/translogic

TransLogic is a registered trademark of Swisslog AG.
 ©2020 Swisslog Healthcare NAM EN 042020 PTS-605